

Stryker PN	Description	Instruction Sheet
3800-103-300	4" DUAL BLACK CENTRAL LOCK CASTER (001621)	QQ-01006
3800-063-300	4" HEX HDW DUAL BLACK DIRECTIONAL LOCK CASTER (001618)	QQ-01007
3800-064-300	4" HEX HDW DUAL BLACK SWIVEL CASTER (001619)	QQ-01008
3800-065-300	4" HEX HDW DUAL BLACK TOTAL LOCK CASTER (001617)	QQ-01009
3800-060-300	4" SINGLE BLACK DIRECTIONAL LOCK CASTER (001916)	QQ-01015
3800-061-300	4" SINGLE BLACK SWIVEL CASTER (001917)	QQ-01016
3800-062-300	4" SINGLE BLACK TOTAL LOCK CASTER (001915)	QQ-01017
3800-082-300	ALOREC/300 SERIES ARM MECH ACTUATOR (SINGLE)	QQ-01100R
3800-057-300	300 SERIES (MANUAL) STD MECHANISM	QQ-30000
3800-058-300	300 SERIES (MANUAL) XL MECHANISM	QQ-30001
3800-059-300	300 SERIES MECH SPRING SET	QQ-30004
3800-074-300	300 SERIES GAS CYLINDER KIT-SINGLE	QQ-30005
3800-045-300	300 SERIES TREND BRACKETS	QQ-30010
3800-047-300	300 SERIES TREND CABLES	QQ-30011
3800-042-300	300 SERIES TREND COVERS	QQ-30012
3800-043-300	300 SERIES TREND HANDLE-STD	QQ-30013
3800-044-300	300 SERIES TREND HANDLE-XL	QQ-30014
3800-104-300	300 SERIES STD PUSH HANDLE	QQ-30015
3800-105-300	300 SERIES XL PUSH HANDLE	QQ-30016
3800-092-300	300 SERIES FOOT TRAY RETRO KIT STD-DUAL CASTER	QQ-30020
3800-093-300	300 SERIES FOOT TRAY RETRO KIT XL-DUAL CASTER	QQ-30021
3800-070-300	300 SERIES FOOT TRAY BASE MOUNTS-DUAL CASTER	QQ-30022
3800-069-300	300 SERIES FOOT TRAY CASTER PAIR-STD KIT	QQ-30023
3800-067-300	300 SERIES FOOT TRAY STD	QQ-30024
3800-068-300	300 SERIES FOOT TRAY XL	QQ-30025
3800-091-300	300 SERIES FOOT TRAY RETRO KIT STD-SINGLE CASTER	QQ-30026
3800-102-300	300 SERIES FOOT TRAY BASE MOUNTS-SINGLE CASTER	QQ-30028
3800-101-300	300 SERIES FOOT TRAY CASTER PAIR-XL KIT	QQ-30029
3800-106-300	300 SERIES STD BASE, NO CASTERS	QQ-30030
3800-107-300	300 SERIES XL BASE, NO CASTERS	QQ-30031
3800-108-300	300 SERIES STD CLC BASE, W/CASTERS	QQ-30032
3800-109-300	300 SERIES XL CLC BASE, W/CASTERS	QQ-30033
3800-071-300	300 SERIES CLC BRAKE PEDAL (SINGLE)	QQ-30050
3800-072-300	300 SERIES CLC BRAKE SHAFT (SINGLE)	QQ-30051
3800-073-300	300 SERIES CLC ROLLER LATCH (SINGLE)	QQ-30052
3800-054-300	300/310 STD FOOTREST, COMPLETE	QQ-30100
3800-055-300	31X XL FOOTREST, COMPLETE	QQ-30101
3800-056-300	CENTERBOARD OR FOOTREST INSTALLATION HARDWARE	QQ-30110
3800-048-300	300 STD SEAT, VALUE	QQ-30200
3800-049-300	310 STD SEAT, PREMIUM	QQ-30201
3800-050-300	31X XL SEAT, PREMIUM	QQ-30202
3800-051-300	300 SERIES SEAT INSTALLATION HARDWARE	QQ-30210
3800-040-300	300/310 STD BACK, W/FRAME	QQ-30300
3800-041-300	31X XL BACK, W/FRAME	QQ-30301
3800-046-300	300 SERIES BACK INSTALLATION THUMB SCREWS	QQ-30302
3800-075-300	300 SERIES LH FIXED ARM - PREMIUM	QQ-30400

3800-079-300	300 SERIES LH/RH TRANSFER ARM - TOP	QQ-30401
3800-080-300	300 SERIES LH TRANSFER ARM - BOTTOM	QQ-30402
3800-076-300	300 SERIES RH FIXED ARM - PREMIUM	QQ-30403
3800-081-300	300 SERIES RH TRANSFER ARM - BOTTOM	QQ-30405
3800-087-300	300 SERIES TRANSFER ARM - BUTTON	QQ-30406
3800-085-300	300 SERIES TRANSFER ARM - DAMPER	QQ-30407
3800-083-300	300 SERIES ARM MOUNTING HARDWARE (SINGLE)	QQ-30408
3800-086-300	300 SERIES TRANSFER ARM - HINGE COVER	QQ-30409
3800-084-300	300 SERIES ARM BRACKETS KIT (SINGLE)	QQ-30410
3800-077-300	300 SERIES LH FIXED ARM - VALUE	QQ-30411
3800-078-300	300 SERIES RH FIXED ARM - VALUE	QQ-30412
3800-110-300	300 SERIES ARM CAP REPLACEMENT KIT (SINGLE)	QQ-30413
3800-089-300	IVPOLE1 - IV POLE, 2 PRONG	QQ-30500
3800-090-300	300 SERIES IV POLE BRACKET, LH/RH	QQ-30501
3800-094-300	300 SERIES PIVOT TABLE, LH	QQ-30502
3800-095-300	300 SERIES PIVOT TABLE, RH	QQ-30503
3800-096-300	HP300 - HEAD PILLOW, STD	QQ-30504
3800-097-300	HP31X - HEAD PILLOW, XL	QQ-30505
3800-098-300	CW - CUSHION WEDGE	QQ-30506
3800-099-300	HDPRO300 - HEAD PROTECTOR, STD	QQ-30507
3800-100-300	HDPRO31X - HEAD PROTECTOR, XL	QQ-30508
3800-088-300	300 SERIES FOLEY HOOK	QQ-30509
3800-052-300	ALOREC/300 SERIES (MANUAL) STD CF CENTERBOARD, COMPLETE	QQ-61200R
3800-053-300	ALOREC/300 SERIES (MANUAL) XL CF CENTERBOARD, COMPLETE	QQ-62200R
3800-111-300	HARDWARE SNAP CAP #180 BLACK WITH WASHER (5M)	QQ-SNAP-CAP