

REF 8001-061-630  
REF 8001-061-635  
REF 8001-061-640  
REF 8001-061-650  
REF 8001-061-660



## Operations Manual Manual de uso Bedienungsanleitung Manuel d'utilisation Manuale d'uso Bedieningshandleiding Användarhandbok Betjäningsmanual Manual de utilização Brukerhåndbok Podręcznik użytkownika Pykočogombo no ekm̤anuamau Kullama Kilavuzu Příručka pro obsluhu 操作手册 작동 설명서



English (EN)  
Español (ES)  
Deutsch (DE)  
Français (FR)  
Italiano (IT)  
Nederlands (NL)  
Svenska (SV)  
Dansk (DA)  
Português (PT)  
Norsk (NN)  
Polski (PL)  
Pycckyu (RU)  
Türkçe (TR)  
Český (CS)  
中文 (ZH-CN)  
한국어 (KO)



2017/05 C.1  
8001-009-151 REV C  
www.stryker.com





Figure 1: Batch lot code  
Figura 1: Código de lote  
Abbildung 1: Chargennummer  
Figure 1: Code de lot  
Figura 1: Codice di lotto  
Afbewerking 1: Batchcode  
Figur 1: Kode til lot  
Figur 1: Lot-kode  
Figur 1: Kod sertis parti  
Pucycek 1: Kod sertis parti  
Pykočogombo 1: Kod sertis parti  
Şekil 1: Parti lot kodu  
Özħrəżek 1: Čislo sertze  
Fig 1:批次代码  
그림 1: 배치 코드



### Contact Information

Contact Stryker Customer Service or Technical Support at 1-800-327-0770.

Stryker Medical  
3800 E. Centre Avenue  
Portage, MI 49002  
USA

To view your product manual online, see <https://techweb.stryker.com>.

Have the Lot batch code (A) (Figure 1) available when you call Customer Service. Include the Lot batch code in all written communication.

### Safety Precautions

- WARNING**
  - Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.
  - Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.
  - Always turn or reposition the patient over the duration of therapy according to hospital protocol.
  - Always keep the area between the patient and the thermal transfer device dry.
  - Application of heat or cold is most effective when you apply the body wrap directly to the skin.
  - Do not allow hoses to fold, kink, or to wrap around a patient.
- CAUTION**
  - Do not use if the package is damaged.
  - Do not connect the thermal transfer device in a series on a single port.
  - Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.
  - Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.
  - Do not allow this product to position or transfer a patient.
  - Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.
  - Always consult the controller operations manual before connecting this product.
  - Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.
  - Do not clean this product. If soiled, dispose of product according to hospital protocol. This is a single patient use product.
  - Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this product to position or transfer a patient.

Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.

Always consult the controller operations manual before connecting this product.

Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.

Do not clean this product. If soiled, dispose of product according to hospital protocol.

This is a single patient use product.

Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this product to position or transfer a patient.

Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.

Always consult the controller operations manual before connecting this product.

Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.

Do not clean this product. If soiled, dispose of product according to hospital protocol.

This is a single patient use product.

Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this product to position or transfer a patient.

Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.

Always consult the controller operations manual before connecting this product.

Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.

Do not clean this product. If soiled, dispose of product according to hospital protocol.

This is a single patient use product.

Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this product to position or transfer a patient.

Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.

Always consult the controller operations manual before connecting this product.

Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.

Do not clean this product. If soiled, dispose of product according to hospital protocol.

This is a single patient use product.

Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this product to position or transfer a patient.

Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.

Always consult the controller operations manual before connecting this product.

Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.

Do not clean this product. If soiled, dispose of product according to hospital protocol.

This is a single patient use product.

Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this product to position or transfer a patient.

Always follow hospital protocol for regulating temperature with external devices. Frequency of assessment and documentation will vary upon the individual response of the patient.

Always consult the controller operations manual before connecting this product.

Always complete a finger check, after applying a vest or wrap, to make sure that it is not on the patient too tight. This check is to avoid the risk of pressure ulcers.

Do not clean this product. If soiled, dispose of product according to hospital protocol.

This is a single patient use product.

Do not block fluid pathways of the thermal transfer device with restraints.

Always check the product for leaks, tears, cuts, holes, stains, or any other damage prior to and during use.

Always turn the patient's skin condition in areas of contact with the blanket according to hospital protocol or as directed by a physician.

Always turn or reposition the patient over the duration of therapy according to hospital protocol.

Always keep the area between the patient and the thermal transfer device dry.

Application of heat or cold is most effective when you apply the body wrap directly to the skin.

Do not allow hoses to fold, kink, or to wrap around a patient.

Do not use if the package is damaged.

Do not connect the thermal transfer device in a series on a single port.

Always use Stryker products with an approved Stryker temperature controller. Using this product with other controllers has not been tested.

Do not reuse this product on another patient to avoid the risk of cross-contamination and infection.

Do not allow this

